

**FAQ: "In EasyMatch QC-ER, do we restrict a user's ability to standardize an instrument without elevated rights?"**

The only people who can standardize the instrument are those included in the QCERAdmins and QCERUsers Groups who have privilege to be able to login to EZMQC-ER.

Everyone in the two groups is assumed to be a Standard User (no System Admin rights) as far as network or local PC status is concerned.

EZMQC-ER encourages standardization of the sensor mode on a regular basis as this is a core feature in maintaining valid color measurements. QCERAdmins and QCERUsers cannot go forward to make measurements if the time is beyond the Sensor/Standardization Interval (8 hours default but can be set tighter).