

PRODUCT INSTALLATION GUIDE

D02-1016-061



DESCRIPTION: Floor mounting Stand for SpectraTrend HT 2.0, single post

PRODUCT USE

Made of 80/20 extrusion, this floor mounting stand provides X, Y and Z adjustability for precise mounting of the SpectraTrend HT over a moving sample in a process stream.

INCLUDED

- 2-piece center post
- 90° Adjustable arm
- 180° Pivoting head

DIMENSIONS

Center Stand Height: 72" (1.83 m)
Adjustable Arm: 33" (0.838 m)

WEIGHT

50 lbs (22.7 kg) includes mounting plate

WEIGHT WITH INSTRUMENT

60.9 lbs (27.6 kg) includes mounting plate

IMPORTANT RECOMMENDATIONS FOR USE:

1. This floor mounting stand should be bolted to the concrete floor using a minimum of two ½" x L 3" long concrete lag bolts,
2. The center post should be mounted in an area where the instrument is accessible for calibration and maintenance purposes.

